



# NATURAL CHEMISTRY



## Filter Perfect™ Instructions

### Directions for use:

#### **For Cartridge Elements and DE Grids:**

1. Remove cartridge elements or D.E. grids from filter tank and hose off loose material.
2. In a container with 5-10 gallons of water, add 1 bottle of **Filter Perfect**.
3. Place cartridge elements or D.E. grids in solution and soak for a minimum of 6 hours (preferably overnight).
4. Remove from solution and rinse thoroughly.
5. Clean cartridge elements should be allowed to dry before reinstalling.

#### **For Sand Filters:**

1. Have pump running and filter in backwash mode. Suction should come primarily from the skimmer, not the main drain.
2. Add one bottle of **Filter Perfect** to the skimmer.
3. Once contents of bottle has entered the filter, turn pump off and put valve in either close or filter position for a minimum of 6 hours.

4. Turn pump on with filter set to backwash and run until water flows clear. Do not allow pump to run dry.
5. Return filter to normal operation.