

**CLEANER**

amerse™  
SPA CARE

Fresh Fill  
Filter



**DIRECTIONS:** Connect the **Amerse Fresh Fill Filter** to a garden hose. Flush filter for approximately 30 seconds before starting to fill. Filters 7,500 Gallons - 28,000 Liters

**USAGE METER**

**Mark a box each time you use the filter with approximate usages.**

Each box represents 500 Gallons / 1,865 Liters:

Mark 1/2 a box for lesser usage.



**When all boxes are marked, it's time to replace the Fresh Fill Filter.**

Do Not Allow to Freeze • After use, stand on large end and let dry 24-48 hours. Once dry, replace end caps and store in a cool, dry place.

Active Ingredient: Activated Carbon  
Removes TOC's, VOC's, Chlorine by-products and suspended solids.

Distributed by

**ESSENTIALS**

© 2017 Cumming, GA 30041 [www.Essentials-SpaSupplies.com](http://www.Essentials-SpaSupplies.com)